

COMMON QUESTIONS AND ANSWERS

Q. The engine will not start or runs rough. What is the problem?

A. Check all connections to insure that they are tight, and in the proper location. Visually check and measure all grounds. Remove paint and corrosion from around the distributor hold down bracket. Make sure that the distributor red and black wire are connected properly. The Ignitor III in the Flame-Thrower distributor will shut down if the wires are incorrectly attached. The Ignitor III is designed to sense high current levels. Check all wires for shorts, correct polarity and that the ignition coil's primary resistance level is acceptable. For more detailed information log on to www.pertronix.com or contact the technical department at (909) 547-9058.

Q. The vehicle will start, but then dies. After waiting, it starts. What is wrong?

A. The Ignitor III in the Flame-Thrower distributor may have a "Low Voltage Problem." If the voltage supplied to the red distributor wire is insufficient, the system may run for a period of time, and then shut down as the voltage drops due to engine heat. The period may vary from minutes to hours depending on available voltage and wiring condition.

Q. How do I check for a "Low Voltage Problem" or determine if I am getting adequate voltage?

A. To quickly test for a "Low Voltage Problem" or for adequate voltage (**Note: This is only a test and is not intended as a permanent fix**) attach a jumper wire from the positive battery terminal to the positive terminal of the coil. Try to start the vehicle. If the vehicle starts, low voltage is present. **Note: If the engine starts. The engine will not turn off unless the jumper wire is removed from the positive battery terminal.** Check connections and insure all external resistors have been removed. For more detailed information on how to locate the source of the voltage drop log on to www.pertronix.com or contact the technical department at (909) 547-9058.

Q. How do I check my coil for primary resistance?

A. Remove all wires from the coil. Set the ohmmeter to the lowest scale. Attach one lead of the meter to the positive coil terminal. Attach the other lead to the negative coil terminal. The Ignitor III in the Flame-Thrower distributor is compatible with coils having a resistance of 0.32 ohms or greater.

Q. May I modify the length of the wires?

A. Yes, you may cut the wires to any length your application requires. You may also add lengths of wire if needed (20-gauge). Make sure that all wire splices are clean and the connections are tight.

Q. Will the Ignitor III in the Flame-Thrower distributor work with aftermarket capacitive discharge boxes?

A. **We recommend the Ignitor or Ignitor II as a trigger source for a capacitive discharge box.** For more detailed information log on to www.pertronix.com or contact the technical department at (909) 547-9058.

Q. How can I receive additional help?

A. Check our web site for current trouble shooting tips and up to date technical information. Log on to www.pertronix.com. You may also contact our tech line at (909) 547-9058.



FORD 2.0L DISTRIBUTOR INSTALLATION INSTRUCTIONS



GENERAL INFORMATION

1. **IMPORTANT:** Read all instructions before starting installation.
2. **For 12-volt negative ground systems only.**
3. New spark plug wires may be required.
4. **WARNING!!! DO NOT USE WITH SOLID CORE IGNITION WIRES.** Use carbon or suppression type spark plug wires.
5. See back page for coil recommendations.

DISTRIBUTOR REMOVAL

1. Crank the engine until the first cylinder in the firing order is at TDC "Top Dead Center" on its compression stroke. The timing indicator should point to TDC or 0.
2. Remove the distributor cap, and make sure that the rotor is pointing towards the contact on the distributor cap for the first cylinder in the firing order.
3. Disconnect the battery cable.
4. Disconnect all wires and hoses attached to the distributor.
5. Remove the distributor hold down bolt and bracket.
6. Remove the distributor from the engine. Note that the rotor rotates as the distributor is being removed and should be taken into account when installing new distributor.
7. Check the distributor gear for signs of excess wear, or potential problems.

DISTRIBUTOR INSTALLATION

Note: Original hold down clamp must be used with new Flame-Thrower distributor. Hold down bracket must be free of paint and corrosion, this will insure that a proper ground is made to the engine block.

8. Remove the Flame-Thrower distributor cap.
9. Turn the shaft so that when the distributor is placed into the engine, the rotor position matches that of the original distributor.
10. Press the distributor down into the engine block. Make sure that the gear and oil pump shaft are fully engaged. You may have to rotate the oil pump shaft for the rotor to line up and for the distributor to seat properly. Note: Improper installation can cause permanent damage to the engine as well as the distributor.
11. Place the distributor cap onto the housing.
12. Turn the distributor housing so that the terminal that represents the first cylinder in the firing order, lines up with the rotor contact terminal.
13. Tighten the distributor clamp and hold down bolts to the engine.
14. Clip the cap into place and install the spark plug wires in the proper firing order.

LIMITED WARRANTY

PerTronix, LLC. warrants to the original Purchaser of its Flame-Thrower Billet distributor that the product shall be free from defects in material and workmanship (normal wear and tear excluded) for a period of 12 months from the date of purchase (30 months when Ignitor III is purchased separately).

If within the period of the foregoing warranty PerTronix finds, after inspection, that the product or any component thereof is defective, PerTronix will, at its option, repair such products or component or replace them with identical or similar parts PROVIDED that within such period Purchaser:

1. Promptly notifies PerTronix, in writing, of such defects.
2. Delivers the defective product or component to PerTronix (Attn: Warranty) with proof of purchase date; and
3. Has installed and used the product in a normal and proper manner, consistent with PerTronix printed instructions

THE FOREGOING LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

THE FURNISHING OF A REPAIR OR REPLACEMENT COMPONENT OR COMPONENTS SHALL CONSTITUTE THE SOLE REMEDY OF PURCHASER AND THE SOLE LIABILITY OF PerTronix WHETHER ON WARRANTY, CONTRACT OR FOR NEGLIGENCE, AND IN NO EVENT WILL PerTronix BE LIABLE FOR MONEY DAMAGES WHETHER DIRECT OR CONSEQUENTIAL.




440 East Arrow Highway
San Dimas, CA 91773
909-599-5955
www.pertronix.com

WIRING

The Flame-Thrower III cast distributor can be used in conjunction with most ignition coils rated at 0.32 ohms or greater. For optimum performance we recommend our Flame-Thrower III canister style or HC e-core coil.

Many vehicles came equipped with ballast resistors or resistance wires. To achieve optimum performance we recommend removal of these components. Determine the proper wire length, and attach the provided terminals. (Use a wire crimping tool to achieve an adequate connection).

1. Attach the **Red wire** to the coil positive terminal or a 12-volt ignition source.
2. Attach the **Black wire** to the coil negative terminal.
3. Check to insure correct polarity and that all connections are tight.
4. Reconnect the battery negative cable.



FINAL ADJUSTMENTS

1. Start the engine and set the initial timing.
2. For Vacuum advance distributors: Locate the vacuum hose that was previously attached to the vacuum advance canister. This hose should originate at a ported vacuum source. Temporarily plug the end of the vacuum hose at the ported end of the hose. Set the timing per the OEM specifications. Securely tighten the hold down bolt. Remove the vacuum plug and reattach hose to the vacuum canister.

REV-LIMITER SETTING PROCEDURE

1. Remove distributor cap and rotor.
2. Turn the ignition key to the 'ON' position. Do not try starting the engine.
3. Turn the Rev-Limit dial clockwise until it stops. Turn the dial counterclockwise until it stops. A slow blinking of the LED indicates that the setting procedure has been initialized and that the Rev-Limit can be set.
4. Turning the dial clockwise sets the Rev-Limit. After turning the dial, pause and watch the LED for verification of the Rev-Limit setting. Long flashes indicate 1000 RPM's and short flashes indicate 100 RPM's. For example, 6 long flashes followed by 2 short flashes means the Rev-Limit is 6200 RPM's. Continue turning the Rev-Limit dial until the desired Rev-Limit is reached.
NOTE: Leaving the Rev-Limit dial in the full counterclockwise position disables the Rev-Limiter.
5. Let the LED sequence thru at least three complete cycles. This verifies the correct setting and prepares the unit for permanent storage of the Rev-Limit.
6. Turn the ignition key off, this signifies to the Ignitor III that the Rev-Limit procedure is complete. **Note: The ignition key MUST be turned off or the engine will not start.**
7. Your rev limit is now set and will not change until you go through this procedure again.
8. Re-install cap and rotor.

NOTE: Setting the rev limit may be done effectively and easily on a bench or table. Connect the module to a 9-volt battery as shown in figure 2. Then follow the setting procedure outlined above.




Figure 2

REV-LIMITER SPECIFICATIONS

Settings	RPM'S
Minimum	4000
Maximum	9000
Factory Setting	5500

GROUND TESTS

It is imperative that the power and grounds be checked as part of the installation procedure. After installing the Ignitor III module and the distributor and with the distributor in the engine, use a digital multi-meter to measure the resistance from the aluminum plate holding the module to battery (-), the net resistance must be less than 0.2 ohms. (Set meter to lowest ohms setting). The net resistance is the meter reading minus the resistance of the meter leads. If the net resistance is greater than 0.2 ohms, the source of the faulty ground must be found and fixed. Usually the source of the bad ground is easily found by holding one probe on an original location and moving the second probe toward the static probe. Where the resistance drops identifies the source.

Maximum resistance from Ignitor plate to battery negative terminal.	0.2 ohms
---	----------

EXAMPLE:

Resistance from Ignitor plate to battery negative (-) terminal.	0.4 ohms
Resistance of meter leads	0.2 ohms
After subtracting meter lead resistance, your net resistance is:	0.2 ohms

VOLTAGE TEST

1. (Do not disconnect wires from Ignition coil). Place ignition switch in the "off" position.
2. Connect a jumper wire from negative (-) terminal of the coil to a good engine ground. **Note: For coils with less than 1.0 ohms of primary resistance add a 1.0 ohm ballast resistor in jumper wire.**
3. Connect the voltmeter red lead to the positive (+) terminal of the coil and the black lead to a good engine ground.
4. Turn the ignition switch to the "on" position and note voltage reading on the voltmeter. Quickly read the voltage and turn ignition "OFF". Leaving ignition "ON" for an extended period could result in permanent damage to the coil.
5. SEE CHART BELOW FOR SPECIFICATIONS.

Note: Low voltage can be caused by poor connections, poor contacts in the ignition switch, ballast resistor, and or a resistance wire in the wiring harness (Factory Installed).

	Minimum	Maximum
Ignition Switch "ON" (with jumper wire)	8.0V	N/A
Cranking (with jumper wire)	8.0V	N/A