

Classic Instruments

Bel Eta

3

Installation Manual

Table of Contents

Welcome from the Team at Classic Instruments!	3
Optional Gear Indicator Mounting.....	4
Gauge Mounting.....	6
Gauge Cluster Wiring	8
Gauge Wiring Diagram	9
Oil Pressure Sender Installation.....	10
Temperature Sender Installation	11
Fuel Gauge Setup	11
Speedometer Calibration	12
Entering Calibration Mode:	12
Speedometer “Instant” Calibration:.....	13
Speedometer “Real-Time” Calibration:	14
Speedometer “Measured Mile” Calibration:.....	15
Reset Gauge Calibration to Factory Defaults:.....	15

Welcome from the Team at Classic Instruments!

Our congratulations and appreciation for your purchase of one of the finest quality sets of specialty instruments ever produced! Your instrument set has been conceived, designed, and manufactured by Classic Instruments, Inc. in the U.S.A. Each instrument has been tested and certified for accuracy and quality before packaging and shipping.

For trouble-free installation and operation follow the instructions exactly as outlined. Your instruments were assembled to precise specifications and although each has a seven (7) year warranty covering defective parts and workmanship – this warranty will not cover instruments or sender units which have been installed incorrectly.

Follow our recommended procedures for installation and proper hookup to maintain the value and appearance of your instrument set during many future years of accurate and dependable service!

LIMITED WARRANTY

Classic Instruments, Inc. (CI) warrants to the original purchaser that any CI product manufactured or supplied by CI will be free from defects in material and workmanship under normal use and service for a period of seven (7) years from date of purchase.

Improper installation, use of sending units other than CI's or attempted repair or adjustments by other than CI shall void this warranty. Disassembly of any instruments or senders for whatever reason shall specifically void this warranty.

It's always easy to look to a part for an issue with your set. Before you conclude that a part may be bad, thoroughly check your work. Today's semiconductors and passive components have reached incredibly high reliability levels, but there is still room for error in our human construction skills. However, on rare occasions a sour part can slip through. Please be aware that testing can usually determine if the part was truly defective or damaged by assembly or usage. Don't be afraid of telling us that you "blew it", we're all human and in most cases, replacement parts are very reasonably priced.

Purchaser requesting a product to be repaired or replaced under warranty must first call CI at 1-800-575-0461 before the return of defective part. Send defective part to 826 Moll Drive, Boyne City, MI 49712, USA. Include a written description of the failure with defective part.

Purchaser agrees and accepts that under no circumstances will a warranty replacement be furnished until CI has first received, inspected, and tested the returned part.

All other warranties expressed or implied are hereby excluded including any implied warranty of merchandise and implied warranty of fitness for a particular purpose. The sole and exclusive remedy for breach of this warranty is limited to the replacement set forth above.

It is expressly agreed that there shall be no further remedy for consequential or other type of damage, including any claim for loss of profit, engine damage or injury.

TECHNICAL ASSISTANCE

1-800-575-0461


OR

Visit our website for the latest in gauge design and updates to our installation manual

www.classicinstruments.com

Optional Gear Indicator Mounting

To mount the optional gear indicator gauge, you will need a new lens (included), two 8-32 x 3/8" screws (included), and the original mechanical gear indicator assembly.




- Remove the pointer from the original mechanical gear indicator assembly.



- Place the new lens in the gear indicator opening of your bezel. Then, place the modified original mechanical gear indicator assembly over the lens.




- Place the new gear indicator gauge on top of modified indicator assembly and secure in place using the two 8-32 x 3/8" screws.



- Continue with the mounting instructions for the main gauge cluster. Route the gear indicator harness through the access hole in the gauge cluster housing when mounting the gauge cluster to the bezel, and then plug into the gear indicator socket on the gauge cluster.


Gauge Mounting

Use the following included hardware to mount your new gauge cluster in an original or reproduction bezel:




- 4 x Rubber Bumpers
- 6 x 8-32 x 3/8" Screws
- 1 x Glass Lens
- 1 x Double Sided Foam Tape
- 1 x Gauge Cluster


- Cut several thin strips of foam tape and attach to the edges of the bezel opening to cushion the lens. Place the new glass lens in your aftermarket or reproduction bezel.



- Place 4 rubber bumpers on the new gauge cluster at the positions shown below.




- Place new gauge cluster into the gauge bezel and secure using the 5 screws.



Gauge Cluster Wiring

- 1) Always disconnect the vehicle battery before wiring any gauge.
- 2) Connect a fused & keyed +12V power source to the **Pink** wire of the gauge wire harness. *We recommend using a dedicated power source (i.e. separate fuse on fuse panel) to avoid possible problems caused by bad “noisy” power.*
- 3) Connect a good chassis ground to the **Black** wire of the gauge wire harness. *We recommend using a dedicated chassis ground (not stacked with other ground wires) to avoid possible problems caused by a bad ground.*
- 4) Connect one of the following speed signals to the **Purple** wire of the gauge wire harness:
 - a. White signal wire from a pulse signal generator [SN16]
 - i. *Connect the RED power wire of the SN16 to the **RED** 5V wire of the gauge wire harness.*
 - ii. *Connect the BLACK ground wire of the SN16 to a good chassis ground.*
 - [OR]
 - b. One (*either*) wire of an electronic transmission 2-wire vehicle speed sensor [VSS].
 - i. *Connect the other wire of the VSS to the same point as the Black ground wire of the gauge wire harness.*
 - [OR]
 - c. Speedometer Signal wire of a vehicle computer [PCM].
 - i. *Also set the filter switch on the back of the gauge cluster to ON.*
- 5) Connect the fuel level signal to the **Tan** wire of the gauge wire harness.
- 6) Connect the temperature signal to the **Green** wire of the gauge wire harness.
- 7) Connect the oil pressure signal to the **Blue** wire of the gauge wire harness.
- 8) Connect dash light power to the **Grey** wire of the gauge wire harness.
- 9) Connect high beam indicator power to the **Green / White** wire of the gauge wire harness.
- 10) Connect right turn indicator power to the **Purple / White** wire of the gauge wire harness.
- 11) Connect left turn indicator power to the **Blue / White** wire of the gauge wire harness.
- 12) Connect the **Brown** wire of the gauge wire harness to one wire of the setup pushbutton.
 - a. *Connect the other wire of the momentary pushbutton to ground.*
- 13) *Optional:* Connect the warning indicator power the **Yellow** wire of the gauge wire harness.
- 14) *Optional:* Connect the warning indicator ground to the **White** wire of the gauge wire harness.


Gauge Wiring Diagram



Oil Pressure Sender Installation

(Part No. SN52)

- 1) Disconnect battery before installation.
- 2) Only install Classic Instruments sending units when the engine is COLD.
- 3) DO NOT use Teflon tape on the threads. These threads are slightly tapered (1/8" NPT) and designed to be self-sealing. The sender uses the threads for its ground connection and sealant may cause a poor ground causing inaccurate readings. If supplemental sealant is needed, we recommend using Loctite C5-A anti-seize. This is a copper based anti-seize which will allow a good electrical connection for the sender ground.
- 4) Connect a wire from the top terminal of the oil pressure sender to the **Blue** wire of the gauge wire harness.



GM Installation: The correct location on most GM V8-engines to install the oil pressure sender is under the distributor housing at the rear of the block.

Use the 2 piece bushing kit provided to allow the sender to be mounted at a 45-degree angle pointing towards the driver's knees. This allows the sender to clear the back of the intake manifold, the underside of the distributor housing and also the firewall.

GM Installation – Big Block Engines: We do NOT recommend installing Classic Instrument's oil pressure sender in the opening located just above the oil filter on some big block GM engines. This location may not be a full-pressure passage but instead a "by-pass" oil passageway. Installing our pressure sender at this location may result in some strange low-pressure readings under certain driving conditions. This does not indicate a defective instrument or sender! It simply means you need to move the sender to the correct location.

GM Installation – LS Engines: Install the sender in the oil bypass housing located just above the oil filter. The housing will need to be drilled and tapped to 1/8" NPT.




LS1 Oil Bypass Housing

Temperature Sender Installation

(Part No. SN12MM, SN22, SN23, SN24 & SN25)

- 1) Disconnect battery before making any connections.
- 2) Install the Classic Instrument's temperature sending unit only when the engine is COLD!
- 3) DO NOT use Teflon tape on the threads. These threads are slightly tapered and designed to be self-sealing. The sender uses the threads for its ground connection and sealant may cause a poor ground causing inaccurate readings. If supplemental sealant is needed, we recommend using Loctite C5-A anti-seize. This is a copper based anti-seize which will allow a good electrical connection for the sender ground.
- 4) Install the temperature sender into the intake manifold of your engine as possible. Installing the sender in the engine cylinder head may cause inaccurate temperature readings.
 - a. On GM "LS" engines, the temperature sender mounts on the passenger side of the engine under the rear cylinder. A 12mm thread sender [Part # SN12mm] is available to fit this location.
- 5) Connect a wire from the top terminal of the temperature sender to the **Green** wire of the gauge wire harness.
- 6) Tighten until snug. DO NOT OVER TIGHTEN!



Fuel Gauge Setup

The fuel gauge of the Belera 3 can be set to work with a number of aftermarket and OEM fuel senders. Set the 10 position selector switch on the back of the gauge to match the fuel sender you are using in your tank. Below is the list of selector positions and their corresponding fuel sender compatibility.

Selector Position	Sender Resistance Range
1	0-30 (GM Type 1964 and earlier)
2	0-90 (GM Type 1966 to 1998)
3	75-10 (Ford Type 1987 and earlier)
4	10-180 (VDO)
5	40-250 (GM Type 1998 and later)
6	16-158 (Ford Type 1987 and later)
7	240-33 (Standard Aftermarket)
8	240-33 (Standard Aftermarket)
9	240-33 (Standard Aftermarket)
0	240-33 (Standard Aftermarket)

Speedometer Calibration

Note: Before performing speedometer calibration, insure you have a good speed signal. Take a test drive and make sure the speedometer shows a speed (even though it may not be correct)! If the speedometer doesn't show a speed, troubleshoot the speed signal.

Only one calibration method is necessary to perform to calibrate the speedometer. Pick the method that works best for you.

- The "Instant" calibration method requires a GPS reference speed signal (or pace car). You will need to drive at 30mph. This method is convenient if the speedometer is more than 10mph off at a known 60mph.
- The "Real-time" calibration method requires a GPS reference speed signal (or pace car). This method allows you to drive at any known speed and make changes to the speedometer reading as you go. This method is best used if the speedometer calibration is less than 10mph off at a known 60mph.
- The "Measured Mile" calibration method requires you to drive a known mile. This is convenient when a GPS is not available to use as a reference and also if the calibration is off more than 10mph at a known 60mph. The speed at which you drive the known mile can be varied, a GPS reference or pace car is not necessary.

Calibration Modes	
Speedometer Indication	Calibration Mode
50 MPH	Speedometer "Instant" Calibration
60 MPH	Speedometer "Real-time" Calibration
70 MPH	Speedometer "Measured Mile" Calibration
80 MPH	Factory Defaults Reset Mode
90 MPH	Exit calibration Mode

Entering Calibration Mode:

- 1) Start with power to the gauge OFF.
 - 2) Press and HOLD the setup pushbutton.
 - 3) Start engine.
 - 4) Release the pushbutton after the engine is started. The speedometer will indicate 50MPH. *The high beam indicator will also be lit [blue] to indicate that the gauge is in calibration mode.*
-

Speedometer “Instant” Calibration:

(steps 1-4 may be skipped if the gauge is already in calibration mode)

- 1) Start with power to the gauge OFF.
- 2) Press and HOLD the setup pushbutton.
- 3) Start engine.
- 4) Release the pushbutton after the engine is started. The speedometer will indicate 50MPH. *The high beam indicator will also be lit [blue] to indicate that the gauge is in calibration mode.*
- 5) If the speedometer pointer is not at 50MPH, tap the pushbutton to cycle the pointer through the calibration modes until it comes back to 50MPH.
- 6) With the speedometer indicating 50MPH, press and hold the pushbutton until the speedometer moves to 0 MPH. *The high beam indicator and turn signal indicators will flash [blue] and [green] when a speed signal is detected. If no signal is detected, only the high beam indicator will be lit a constant [blue].*
- 7) Drive the vehicle at exactly 30MPH using a GPS or pace car as a reference. Press and hold the pushbutton while traveling 30MPH. *The turn signal indicators will turn off while the button is pressed. When the calibration is completed, the speedometer will move to indicate 30MPH at which point the pushbutton may be released. The turn signal indicators will also be lit [green] to indicate a successful calibration.*
- 8) If you are satisfied with the speedometer calibration, tap the pushbutton to get back to the calibration mode options. If you would like to re-do the calibration, press and hold the pushbutton to restart the Instant Calibration process.
- 9) When you are finished, tap the pushbutton (as many times as needed) to move the speedometer pointer through the calibration modes to get to the 90MPH (Exit Calibration Mode) option. With the pointer at 90MPH, press and hold the pushbutton for about 6 seconds until the speedometer moves down and starts indicating your actual speed. The speedometer calibration is now saved. *(The turn signal indicators will remain lit until you cycle power to the gauge.)*

Speedometer “Real-Time” Calibration:

(steps 1-4 may be skipped if the gauge is already in calibration mode)

- 1) Start with power to the gauge OFF.
- 2) Press and HOLD the setup pushbutton.
- 3) Start engine.
- 4) Release the pushbutton after the engine is started. The speedometer will indicate 50MPH. *The high beam indicator will also be lit [blue] to indicate that the gauge is in calibration mode.*
- 5) Tap the pushbutton once to move the speedometer pointer up to 60MPH. *If you missed stopping the pointer at 60MPH, continue to tap the pushbutton to cycle the pointer through the calibration modes until it comes back to 60MPH.*
- 6) With the speedometer indicating 60MPH, press and hold the pushbutton until the speedometer changes to 0 MPH.
- 7) Begin driving a known speed using a GPS or pace vehicle as a reference.
- 8) Press and hold the pushbutton to slowly change the indicated speed. The first time the pushbutton is pressed will increase the speedometer reading. The next time the pushbutton is pressed will decrease the speedometer reading. The speedometer will alternate between increasing and decreasing speed each time the pushbutton is pressed and held. *The high beam indicator and turn signal indicators will flash [blue] and [green] if a speed signal is detected. If no signal is detected, only the high beam indicator will be lit a constant [blue].*
- 9) Continue to press and hold the pushbutton until the speedometer is indicating the correct speed.
- 10) Once the correct speed is dialed in on the speedometer, wait 10 seconds without pressing the pushbutton *(until the turn signal indicators stop flashing and remain lit [green])* to have the current calibration saved. *If you still need to adjust the speed after this 10 second timeout, press and hold the button to re-enter the “Real Time” calibration mode again.*
- 11) If you are satisfied with the speedometer calibration, tap the pushbutton (as many times as needed) to move the speedometer pointer through the calibration modes to get to the 90MPH (Exit Calibration Mode) option. With the pointer at 90MPH, press and hold the pushbutton for about 6 seconds until the speedometer moves down and starts indicating your actual speed. The speedometer calibration is now saved. *(The turn signal indicators will remain lit until you cycle power to the gauge.)*

Speedometer “Measured Mile” Calibration:

(steps 1-4 may be skipped if the gauge is already in calibration mode)

- 1) Start with power to the gauge OFF.
- 2) Press and HOLD the setup pushbutton.
- 3) Start engine.
- 4) Release the pushbutton after the engine is started. The speedometer will indicate 50MPH. *The high beam indicator will also be lit [blue] to indicate that the gauge is in calibration mode.*
- 5) Tap the pushbutton twice to move the speedometer pointer up to 70MPH. *If you missed stopping the pointer at 70MPH, continue to tap the pushbutton to cycle the pointer through the calibration modes until it comes back to 70MPH.*
- 6) With the speedometer indicating 70MPH, press and hold the pushbutton until the speedometer changes to 30 MPH.
- 7) Begin driving a known measured mile. While driving, *the high beam indicator and turn signal indicators will flash [blue] and [green] to indicate a good speed signal. If no signal is detected, only the high beam indicator will be lit a constant [blue].* The speed at which you drive the mile does not matter.
- 8) At the end of the mile, press and hold the pushbutton until the speedometer moves from 30MPH back up to 90MPH. *The turn signal indicators will be lit [green] to indicate a successful calibration. (To get a more accurate calibration, stop at the end of the mile.)*
- 9) If you are satisfied with the speedometer calibration, tap the pushbutton (as many times as needed) to move the speedometer pointer through the calibration modes to get to the 90MPH (Exit Calibration Mode) option. With the pointer at 90MPH, press and hold the pushbutton for about 6 seconds until the speedometer moves down and starts indicating your actual speed. The speedometer calibration is now saved. *(The turn signal indicators will remain lit until you cycle power to the gauge.)*

Reset Gauge Calibration to Factory Defaults:

(steps 1-4 may be skipped if the gauge is already in calibration mode)

- 1) Start with power to the gauge OFF.
- 2) Press and HOLD the setup pushbutton.
- 3) Start engine *(or just turn the key ON).*
- 4) Release the pushbutton after the engine is started *(or the key has been turned ON).* The speedometer will indicate 50MPH. *The high beam indicator will also be lit [blue] to indicate that the gauge is in calibration mode.*
- 5) Tap the pushbutton three times to move the speedometer pointer up to 80MPH. *If you missed stopping the pointer at 80MPH, continue to tap the pushbutton to cycle the pointer through the calibration modes until it comes back to 80MPH.*
- 6) With the speedometer indicating 80MPH, press and hold the pushbutton until the speedometer changes to 90 MPH. *The turn signal indicators will be lit [green] to indicate the gauge has been restored to the factory default settings.*
- 7) With the speedometer pointer at 90MPH, press and hold the pushbutton for about 6 seconds until the speedometer pointer moves down to zero. *(The turn signal indicators will remain lit until you cycle power to the gauge.)*