

HEADER INSTALLATION INSTRUCTIONS

PART NUMBER: D358
1958-64 Chevrolet 265-400 SBC



This product is Legal for use on 1974 Non-Catalyst equipped vehicles and is considered a "Replacement Part" per California Air Resources Board regulations, as long as ALL emissions sensitive components are retained, including EGR, A.I.R., Heat Risers etc. Failure to retain any of these components, or use on 1975 or newer Catalyst equipped vehicles, would render this product Illegal for Street or Off Highway use and may only be used for Closed Course Competition.

PerTronix® thanks you for choosing **DOUG'S HEADERS**, the best fitting, highest quality header on the market. In order to realize the full potential of our good fit, please read and understand these instructions completely prior to starting work.

Check to make sure you received the proper parts for your application. The header number will be stamped on the engine flange. If you are unsure you have received the proper parts call before you start work.

Be sure to work safe! Whenever you work under the vehicle be sure that it is located on level, solid ground and is supported by adequate safety stands! **Remember: Hot asphalt will not support most jack stands!**

Many factors affect the installation of headers, some of which are broken or aftermarket motor mounts, accidents that impact the configuration of the frame, and/or the installation of different engines or aftermarket cylinder heads.

Attention Customers breaking in new engines: Due to the extreme heat generated during the break-in process, the appearance of the ceramic coating may be altered in certain areas. The protection characteristics and thermal barrier properties of the coating is never compromised. It is recommended that a cast iron manifold or old set of headers be used for this process.

Notice: The coating of these headers can be marred or scratched during installation. If the header needs to be returned and is damaged, you will be charged for recoat.

DISASSEMBLY

1. Disconnect the negative battery cable from the battery.
2. If a car lift is not available, raise the vehicle 2 feet or higher and support with adequate safety stands. Make sure the vehicle is on a flat solid surface and is stable.
3. Remove bolts attaching head pipes stock manifolds, then remove the stock manifolds from the car.
4. Remove the Oil Dipstick Tube, Starter, Clutch or Automatic linkage, Oil Filter, and Oil Filter Adapter.
5. Remove the Spark Plug Wires and Spark Plugs. Remove the Generator/Alternator.
6. Remove the A/C compressor if it is mounted to the left side manifold.
7. Clean the cylinder head exhaust mounting surface.

INSTALLATION

1. Remove the center bolt from the Driver's side motor mount and raise the motor approximately 2"
2. From underneath, slip the header up into position.
3. Lower the motor and replace the motor mount bolt.

4. Using the supplied Header bolts and lock washers, slip the gasket in place and start header bolts at each end of the flange. Install remainder of the bolts and tighten from the center and working outwards.
5. Remove the center bolt from the Passenger side motor mount and raise the motor approximately 2"
6. From underneath, slip the header up into position. Leave loose and work the starter into location. Bolt the starter in place
7. Lower the motor and replace the motor mount bolt.
8. Using the supplied Header bolts, slip the gasket in place and start header bolts at each end of the flange. Install remainder of the bolts and tighten from the center and working outwards.
9. Replace the clutch or automatic linkage (column shifted cars may require you to bend the bell crank flat to clear the headers), dipstick tube, generator (bracket part Number H7606/H7607 may be necessary), spark plugs and wires.
10. If the A/C compressor is on the left side you will need bracket part #H7608.
11. Bolt the supplied reducers to the headers using the gaskets, bolts, nuts and washers.
12. Connect the negative battery cable.

IMPORTANT CHECK LIST

- Be sure that all brake lines and fuel lines are clear of headers and/or connector pipes.
- All spark plug wires, battery cables, or other electrical components should be clear of headers and/or connector pipes.
- If dipstick tube was removed, make sure it is installed properly and that the dipstick has been replaced.
- Double-check the tightness of all bolts including brackets and accessories.

STARTING THE ENGINE

Start the engine and allow it to warm up to operating temperature. Check for any unusual noises or exhaust leaks. If every thing is OK, stop the engine and tighten all bolts while the engine is still warm.

NOTE: Check the bolts periodically to make sure they have not loosened. Re-tighten after the first 500 miles and then again at 1000 miles.

PARTS LIST

Qty	Description		
1	Left side header	1	Right side header
2	Header gaskets	12	3/8 X 1" header bolts
18	3/8 Lock-washer	6	3/8-16 x 1 1/4" Collector Hex head bolts
6	3/8-16 Hex Nuts	2	Reducers
2	Collector Gaskets		

WARNING:

This product can expose you to chemicals including Lead, Nickel, Cadmium and Chromium which are known to the State of California to cause cancer and birth defects or other reproductive harm. **For more information go to**
www.P65Warnings.ca.gov