



Installation Instructions  
**718146**  
 2021-26 FORD BRONCO TWO-DOOR  
 WITH 2.3L & 2.7L ENGINE

**OVERVIEW:**

1. Take a moment to read and understand these instructions before installing your Flowmaster performance exhaust.

**NOTES**

- Before starting, use the parts list and drawing to verify your kit's contents. In the unlikely event that any parts are missing, please contact Flowmaster Technical Support for replacements.
- Instruction photos show installation of a similar kit on a 4-door Bronco. But the removal and installation procedures are identical, and the parts list and drawing are correct for the 2-door kit.

ITEM	PART NO.	DESCRIPTION	QTY.
1	26905M	INLET PIPE ASSY	1
2	26906M	MID PIPE ASSY	1
3	70009-595	FLOWFX MUFFLER ASSY	1
4	529HA	RIGHT HANGER ASSY	1
5	530HA	LEFT HANGER ASSY	1
6	MC300BS	CLAMP, STAINLESS, 3"	2
7	HA168	HANGER, RED RUBBER	2
8	HW208	BOLT, 3/8-16 x 1"	2
9	HW103	NUT, 3/8-16	2
10	HW303	FLAT WASHER, 3/8"	2
11	HW309	LOCK WASHER, 3/8"	3
12	HW502	HANGER KEEPER, 7/16"	4
13	HW503	HANGER KEEPER, 1/2"	1
14	3401401	LOCK NUT, M8 x 1.25	2
15	HW274	BOLT, SHLDR 1/2"D x 3/4"L, 3/8-16	1

**REMOVE STOCK EXHAUST SYSTEM:**

2. Raise vehicle up on a hoist or rack to working height. If you don't have access to a hoist or rack, support vehicle with jack stands.

**WARNING**

Avoid serious burns! Allow your vehicle time to cool completely before touching any factory engine components.

**To ease preparation and installation of your new kit:**

- Apply penetrating lubricant to mounts, bolts and clamps before you remove them.
- Use stands as necessary to support parts as you detach them from your vehicle and again as you install new parts.

