



CUT OUT ALONG THIS LINE

FRONT OF VENT WINDOW

11 1/8" FROM FRONT TIP OF MIRROR TO FRONT TIP OF DOOR

CENTER PUNCH & DRILL 1/8" HOLE

END OF VENT WINDOW

WINDOW EDGE

CUT OUT ALONG THIS LINE

CENTER PUNCH & DRILL 1/8" HOLE

CENTER PUNCH & DRILL 1/8" PILOT HOLE

3/4" TRANSMISSION CABLE HOLE