



OUTLAW

S E R I E S

Installation Instructions

818144

2021-26 FORD BRONCO TWO-DOOR WITH 2.3L & 2.7L ENGINE

OVERVIEW:

1. Take a moment to read and understand these instructions before installing your Flowmaster performance exhaust.

NOTES

- Before starting, use the parts list and drawing to verify your kit's contents. In the unlikely event that any parts are missing, please contact Flowmaster Technical Support for replacements.
- Instruction photos show installation of a similar kit on a 4-door Bronco. But the removal and installation procedures are identical, and the parts list and drawing are correct for the 2-door kit.

ITEM	PART NO.	DESCRIPTION	QTY.
1	26905S	INLET PIPE ASSY	1
2	26906S	MID PIPE ASSY	1
3	8430152-592	OUTLAW MUFFLER ASSY	1
4	529HA	RIGHT HANGER ASSY	1
5	530HA	LEFT HANGER ASSY	1
6	MC300BS	CLAMP, STAINLESS, 3"	2
7	HA168	HANGER, RED RUBBER	2
8	HW208	BOLT, 3/8-16 x 1"	2
9	HW103	NUT, 3/8-16	2
10	HW303	FLAT WASHER, 3/8"	2
11	HW309	LOCK WASHER, 3/8"	3
12	HW502	HANGER KEEPER, 7/16"	4
13	HW503	HANGER KEEPER, 1/2"	1
14	3401401	LOCK NUT, M8 x 1.25	2
15	HW274	BOLT, SHLDR 1/2"D x 3/4"L, 3/8-16	1

REMOVE STOCK EXHAUST SYSTEM:

2. Raise vehicle up on a hoist or rack to working height. If you don't have access to a hoist or rack, support vehicle with jack stands.

WARNING

Avoid serious burns! Allow your vehicle time to cool completely before touching any factory engine components.

To ease preparation and installation of your new kit:

- Apply penetrating lubricant to mounts, bolts and clamps before you remove them.
- Use stands as necessary to support parts as you detach them from your vehicle and again as you install new parts.

