

Instructions

Front Swaybar Kit

N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Page 1 of 2

Application - GM Silverado/Sierra
- Tahoe/Suburban/Yukon

Always refer complete catalogue listing

- Raise vehicle evenly and safely support with stands.

Never rely on a Jack only

Note - lubricate all bolts prior to removal

- Un-bolt and remove original links and saddles.
- Grease new bushings with supplied grease only - place over swaybar.
- Using original saddles and bolts, mount swaybar to vehicle with supplied flat washers.

Contents - 1x Front swaybar 33mm

- 2x Mount bushings 91521
- 4x Mount washers
- 8x Link bushings 90741
- 2x Link bolts
- 2x Nyloc nuts
- 2x Link steel tubes
- 8x cupped washers
- Grease



• Assemble link as per image - do not tighten yet.

• Place link washers so they cup 'away' from bushing.

- Nyloc nut
- Link bushing
- Cupped washer
- Steel tube

N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.

Instructions

Front Swaybar Kit

N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Continued - page 2 of 2;

- Confirm swaybar is central and no clearance issues.
- Proceed to tighten link nuts



Note - links are best tightened when vehicle is at ride height.

- Do not over-tighten link bushings. Squashing the bushings may result in premature failure.
- Road test and re-check all nuts and bolts.
- Re-check after 100kms



Please drive safely while you accustom yourself yo the vehicles changed behaviour