

# Fitting Instructions #Z7008

Jeep Liberty / Grand Cherokee KJ

## Front Control Arm Lower-Shock Mount Kit

The information is for reference only.

**Note:** Polyurethane bushes must be fitted to both sides of the vehicle.

- Wheel-align the vehicle before the job is started and note settings;
- Jack the vehicle up and support on jack stands;
- Remove the lower control arms;
- Remove original shell parts from the housing with the use of a hydraulic press and suitable pressing tools;
- Alternatively, you may remove the original shell part by burning the rubber bushing and cutting the shell out. Care must be taken to not damage the housing while performing the cut;
- Clean housing areas to remove remaining OE bush material;
- With reference to the diagram, note the position of the new steel shell polyurethane bushes in the arm, then push them into their respective housing;

- Refit the control arm to the vehicle. Tighten all bolts to manufacture's torque settings;
- Carry out wheel alignment.

