

Instructions

Rear Swaybar Kit

N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Page 1 of 2

Application - GM Silverado/Sierra
- Tahoe/Suburban/Yukon

Always refer complete catalogue listing

- Raise vehicle evenly and safely support with stands.

Never rely on a Jack only

Note - lubricate all bolts prior to removal

- Un-bolt and remove original saddles. Un-bolt swaybar link at swaybar end.
- Grease new bushings with supplied grease only - place over swaybar.

Contents - 1x Front swaybar 30mm

- 2x Mount bushings SB30
- 2x Mount saddles
- 4x Mount washers
- Grease



- Remove OE link nut.

Check OE link condition - check for any movement or torn boots.

Replace old link if necessary.

N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.

Instructions

Rear Swaybar Kit

N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Continued - page 2 of 2;

- This swaybar kit is supplied with new steel saddles - mount swaybar onto axle with new saddles and 4 flat washers.
- Bolt up swaybar links.
- Confirm swaybar is central and no clearance issues.
- Road test and re-ck all nuts and bolts.
- Re-check after 100kms travelled.



Please drive safely while you accustom yourself yo the vehicles changed behaviour