

Instructions

Rear Swaybar Kit

N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Application:
Chevrolet C10

Kit Contents:

1x Swaybar
4x U-bolts - select 2
4x Axle brackets - select 2
2x Flat plates
2x Saddles
2x D bushings
2x 8 inch Bolts
8x Cupped washers
6x Nyloc nuts
4x Flat washers
8x Cupped washers
8x Link bushings

1. Raise vehicle evenly and safely support.
2. Grease and position D bushings on swaybar.
3. Select appropriate size U bolts and Axle brackets to suit your Axle (there are 2 sizes supplied) - proceed to hang swaybar as per image 1. Confirm swaybar is central.

NOTE - careful U bolts are not near brake lines.

4. Assemble swaybar link bolts to swaybar initially, using supplied bushings and cupped washers - position cupped washers so they face away from bushing. Raise swaybar and mark chassis rail for the link - drill a 13mm (half-inch) hole.
5. Proceed to assemble swaybar link to chassis rail - position cup washers so they face away from bushing. This is best done at ride height - confirm link is perpendicular to swaybar link hole - refer image 2.

NOTE - do not over tighten link bushings.

6. Road test and re-check all nuts bolts.

Image 1



Image 2



N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.