

Instructions

Sub-frame Bushings

N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

1. Raise vehicle evenly and safely support.

Bushings can be replaced in the vehicle.

2. Proceed to lower the rear of Sub-frame down
Refer workshop manual for best method.

3. Using a mechanical puller (bolt/nut and steel cup),
Press the original bushings out.
Alternatively drill hole in rubber and cut outer shell.

4. Clean Sub-frame. Place bushing 90571 in from the top side. And bushing 90572 in from bottom.

5. Lightly grease bushing ID and faces with supplied grease only - now push in supplied steel tubes. Add washers to top and bottom sides.

6. Bolt up Sub-frame - tighten bolts to manufacturers specifications.

7. Re-check after initial 100kms travelled.

Application - VW/Audi
- Various platforms
(Refer current catalogue listing)

Contents - 2x Bushing 90571
- 2x Bushing 90572
- 2x Steel tubes
- 2x Steel washers
- grease



N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.