



**DO NOT** connect 12V to the sender. Doing so will damage the sender and void warranty.



828 Moll Drive - Bayne City, Michigan 48712

Tube Style Fuel Sending Unit

Overview

Wire Connection Diagram

Date 1/16/18