



Instructions Front Control Arm - Geometry Correction

Page 1 of 2

Suits Forged Aluminium Arm Only

Application - Hyundai I30
- Hyundai Elantra


Always refer complete catalogue listing

Contents - 2x elastomer surrounded spherical bushings
- 2x 6mm spacers

N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

- Raise vehicle evenly and safely support.
- Proceed to remove front wheels and un-bolt front control arms.
Note - a mallet will be needed to loosen the splines on the ball joint platform.
- Using a Press, press out original rubber bushing (including outer steel shell).
- Proceed to press in supplied performance bushing - note bushing is offset for increased caster.
- Place bushing number (69161) 'upwards'.
- Off-set bushing as per image.

The bushing number should be approx. 90 degrees to the front bushing's axis.



N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.



Instructions

Front Control Arm

- Geometry Correction

Continued - Page 2 of 2

Geometry Adjustment - spacer fitment

The supplied spacer may be placed in 1 of 2 places depending on drivers preference/driving style.



- Place 6mm spacer on high side
- **this will promote better power delivery to the ground.**



- Place 6mm spacer on low side
- **this will promote improved stability under brakes**
- Re-use all original nuts and bolts - tighten to manufacturers spec.
- A wheel alignment will be required to correct front Toe setting.
- Road test. Re-check bolts after 100kms travelled.

N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.